



- NOTES:
- 1) X2 TERMINAL GROUNDED AS STANDARD, REMOVE GROUND IF NOT REQUIRED.
 - 2) RCD: STANDS FOR REMOTE CONTROL DEVICE BY CUSTOMER.
 - 3) [] : FOR MULTIFUNCTION TERMINAL NUMBERS.
 - 4) () : FOR ALT. AUX. CONTACT TERMINAL NUMBERS.

-	-	-	-	<p>NOTICE</p> <p>THIS DRAWING IS THE CONFIDENTIAL PROPERTY OF SPRECHER-SCHUH, INC. and, as such, is subject to recall at any time. The drawing may not be reproduced, used or disclosed for any purpose except as authorized by SPRECHER-SCHUH, INC.</p>	DRAWN BY: GS	<p>FVNR MAGNETIC STARTER W/ SS PILOT DEVICES THREE PHASE</p>	<p>sprecher+schuh HOUSTON, TEXAS</p>			
-	-	-	-		CHECKED BY: MB			DWG. NO.	SHEET 1 OF 1	SERIES
-	-	-	-		APPROVED BY: JR			CAT WS-101-01		100
14	GENERAL REVISIONS	04-23-12	MR		DATE					
REV	CHANGE	DATE	BY		04-13-09					