








L7 Switch Accessories

Accessory	Description	Catalog Number
 <p>(Reducer included)</p>	<p>End Shaft - for LE switch ②</p> <ul style="list-style-type: none"> Replacement 44mm shaft supplied standard with all switches Sold only in packages of 2. Order 2 pieces to receive 1 pkg of 2. 	<p>Plastic L2-G3380 Metal L7-G3688 ①</p>
	<p>Terminal cover - 3 pole</p> <p>LE/LA7-16 LE/LA7-25/32 LE/LA7-40/63 LE/LA7-80/100</p> <ul style="list-style-type: none"> Sold only in packages of 2. Order 2 pieces to receive 1 pkg of 2. 	<p>L7-16-C3 L7-25-C3 L7-40-C3 L7-80-C3</p>
	<p>Terminal cover - 3 & 4th pole</p> <p>LE/LA7-25/32 LE/LA7-40/63 LE/LA7-80/100</p> <ul style="list-style-type: none"> Sold only in complete packages. Order 1 to receive 1 pkg of 4 pieces. 	<p>L7-25-C4 L7-40-C4 L7-80-C4</p>
	<p>6 Pole Mechanical Coupling - ②③</p> <p>joins two L7 switches (front or base mount) to form a 6 pole switch (includes 44 mm metal End Shafts for both LE and LA switch)</p> <p>LE7-16 LE/LA7-25 & 32 LE/LA7-40 & 63 LE/LA7-80 & 100</p>	<p>L7-G3821 L7-G3660 L7-G3661 L7-G3662</p>
	<p>Handle Assembly Wrench</p> <p>Used for tightening LA7-S-_ handles during assembly</p>	<p>LA7-N245</p>



① LE7-40...100 3-pole switches and LE7-16...100 6-pole/Changeover switches come standard with a 44mm **metal** End Shaft. LE7-16...32 3-pole switches come standard with a 44mm **plastic** End Shaft.

② When using mechanical coupler to join two LE7 or LA7 three pole switches, terminal markings will be:  To obtain terminal markings  order six pole switch from pages L5 and L7. Coupling for changeover switch is not available.

③ Mechanical couplings applied to all LE7 front mount switches must use LFS2- 48x48 or 64x64 type handles. 6-Pole Mechanical Couplings are not designed for use with LFS2- 88x88 or 90x90 type handles. Mechanical couplings applied to all LA7 base mount switches may use all types of LFS2 handles where applicable.